



3G intercom application operation manual

Android/IOS systems can be installed at our device as below MODEL:
SS91B, SS1404, SS1401, SS1106, SS1104, SS1204AO-12(SINGLE),
SS1206, SS1204AO-12(MULTI), SS1204

Please install follow by manual instruction and operate it via application


THE PROCESS AS FOLLOWS

CHAPTER 1	1
1 USER SETUP	1
1.1. DEVICE SETUP	1
1.2. OPERATE INTERFACE	1
1.3. APPLICATIONS PASSWORD	2
CHAPTER 2	3
2. ADMIN SETTING	3
2.1. PASSWORD	3
2.2. TIME	3
2.3. VOLUME	4
2.4. CALL-IN NUMBER	4
2.5. PIN CODE (KEYPAD INTERCOM & OPENER)	4
2.6. CALL-OUT NUMBER	5
CHAPTER 3	6
3.1. COMMAND SEND OUT VIA SMS	6
3.2. CHECK ALL LOGGED DOOR ACCESS EVENTS (LOG)	7
3.3. RELOAD LAST RECORD NUMBERS SETUP	7

1 USER SETUP

1.1.DEVICE SETUP


A.How to add New Device




NOTE:

- "Name" : Set the device name
- "Tel" : Please add it for device's numbers
- "Model" : choose device's model number
- "Password" : enter device's access control password (5678 Default)

B.How to Delete device



1.2.OPERATE INTERFACE




NOTE:

- "Call Device" : Press this Call Icon (Blue) it will make call to device and Gate will be activated trigger to open this gate.
- "Send SMS" : Send SMS to activate two trigger . Each trigger had three(3) control model : Trigger/Hold/released.
- "Check" : Send SMS back to check signal reception and trigger situation . °


1.3.APPLICATIONS PASSWORD

A.App password setup


step 1



step 2



step 3




NOTE:


If password is lost, please uninstall and install it again.

B.Changed password

step 1




step 2



C.Password protected

step 1




step 2




D.Sort field in the list

step 1



step 2




E.Sort Filed by requested

step 1



step 2



CHAPTER 2

2. ADMIN SETTING


step 1




step 2



step 3



step 4




NOTE:


- 1.administrator function setup : password, Time, Volume , Dial into number, keypad password , Dial out number
- 2.To save TEXT costs, suggest finished All commands and sent out by SMS together in one time

2.1. PASSWORD

step 1



step 2




NOTE:



- “Setting” : setting password
- “Access control” : Access door password
- “Monitoring” : Monitoring password

2.2. TIME

step 1



step 2




NOTE:


- “Relay 1” : Relay 1 time.(sec)
- “Relay 2” : Relay 2 time.(sec)
- “Call divert” : Ring Bell Time setup for call out to mobile phone .(sec)
- “Call” : Talk time duration.(sec)
- “Call in delay” : while wait for connecting time to answer party .(sec)
- “Monitoring” : Monitor time.(min)

2.3. VOLUME

step 1



step 2



NOTE:

"Speaker" : Adjust Device speaker volume

"Mic" : Adjust mic volume

2.4. CALL - IN NUMBER


step 1





step 2



step 3




step 4




2.5. PIN CODE (KEYPAD INTERCOM & OPENER)

step 1


A.Single password



step 2



step 3




NOTE:

Mode:


Single : password number (1-14 digits)

Multi-users : apartment number(1-4 digits) + password number(1-9 digits)


step 1




step 2



step 3




step 4




2.6. CALL - OUT NUMBER

A. Add account number (Multi only)


step 1



step 2




step 3




NOTE:
"+" & "-" : Multi only

B.Delete households number (Multi only)

step 1



step 2



step 3




C. Add dial out number

D. Delete dial out number

step 1

Click “📞📞📞”




step 2

Enter 1- 20 digits




step 3



step 1

Click “ ” to delete number



step 2




NOTE:
 White:Not entered
 Green:Used number
 Red:delete number

CHAPTER 3

3.1. COMMAND SEND OUT VIA SMS


Check All command shown at “field” under Administrator mode

step 1




Click “SMS”

step 2



Send “SMS”

step 3



Swipe left

step 4



Click “SMS”

step 5



Send “SMS”

NOTE:
 If over 140 charator, go to step 3

3.2. CHECK ALL LOGGED DOOR ACCESS EVENTS (LOG)

Click “”

step 1



The screenshot shows the 'Admin Setting' screen with a 'test' button in the top right corner. Below the settings, there is a text field containing a phone number and a 'Send SMS' button at the bottom.

step 2



Type	OP	Content
Password	M	Setting Password : 1234 2017/01/07 10:13:06
Password	M	Access control Password : 5678 2017/01/07 10:13:06
Password	M	Monitoring Password : 6789 2017/01/07 10:13:06
Call-in NO.	M	Country Code : 886 2017/01/07 10:13:06
Call-in NO.	N	Relay/2 Phone NO. : 12345678901234 2017/01/07 10:13:06
Volume	M	Speaker : 4 2017/01/07 10:13:06
Volume	M	Mic : 2 2017/01/07 10:13:06

NOTE:
SMS all sent, APP LOG will be the correct record

3.3. RELOAD LAST RECORD NUMBERS SETUP


Click “”

step 1



The screenshot shows the 'Time' setup screen with various time-related settings. A download icon is visible in the top right corner. The settings include Relay1, Relay2, Call divert, Call, Call in delay, and Monitoring, each with a corresponding time value in parentheses.

step 2



The screenshot shows the 'Time' setup screen after reloading the last record numbers. The values for Relay1, Relay2, Call divert, Call, Call in delay, and Monitoring are now 2, 3, 11, 6, 10, and 1 respectively.

NOTE:
User can load it back just press “” information.
App will display last record message and user can modify it by themselves.